

SEE HOW YOU MEASURE UP


Ensuring that your motorcycle suit fits properly is crucial for many reasons. If it pinches or is too tight, it will detract from your ability to concentrate on the road. The same is true for flapping and fluttering.

Your nerves will fray, your strength will sap away more quickly and as a result your safety may suffer.

Another important issue is to make sure that your trousers and jacket fit well – jacket sleeves and trouser legs must not ride up. This is another important aspect affecting weather protection and safety. For this reason, all our suits are cut in a motorcycle-specific style and feature a multitude of different adjusters, expanding pleats and other well-planned details.

But the initial specification of your size is the most essential aspect of ensuring that the suit you order fits you "like a glove". More than 40 sizes are available to accommodate virtually every figure. Be sure to measure yourself exactly. The following section contains precise information for doing just that.

It would be best to ask someone else to do the actual measuring. Stand relaxed with your arms at your sides. Keep the tape measure snug against your body and be sure to keep it horizontal when passing it round your body.



How to work out your own size:

- A Height**
Stand barefoot against a door frame. Place a book flat on your head and then mark and measure its position.
- B Chest**
This is taken over a shirt or light sweater. The tape is passed under the arms and around the widest point of the chest and shoulder blades.
- C Waist**
This is taken round the shirt and not the waistband of the trousers. Please ensure that you maintain a natural posture. Do not draw in your stomach. Take the measurement as loosely as you want your trouser fit to be.
- D Hips**
This is taken around the trousers at the widest point, measuring all the way around the body.
- E Side length**
This is measured on the outside of the leg, from the waistband to the sole of the foot.
- F Inside length**
This is measured from the inside leg – from the crotch to the sole of the foot.